Sandstrøm

Instruction Manual

DVD Player

S1HDVD10

Sandstrom S1HDVD10_IB_100617_Zell.indd 1 17/06/2010 10:29 AM

Sandstrom S1HDVD10_IB_100617_Zell.indd 2 17/06/2010 10:29 AM

Contents

Unpacking **3**

Product Overview **4**

Front Panel 4
Rear Panel 4
Remote Control 5
Installing the Batteries 7
Handling the Batteries 7
Handling the Remote Control 8
Remote Control Operation Range 8

Connections **9**

1. Connecting to Devices with an HDMI Cable 9
2. Connecting to a TV with a SCART Cable 9
3. Connecting to a Stereo System with an Audio Cable 9
Connecting to the Mains Socket 10

Compatible Disc Types **11**

Supported Formats 11
Region Code 11

Start Up **12**

Basic Playback **12**

Stop Playback 12
Previous and Next 12
Fast Forward and Fast Reverse 12
Pause Playback 13
Single Step Playback 13
Volume Adjustment 13

Advanced Playback **13**

DVD/USB 13
Search 13
Program 14
OSD 14
Title 14
Subtitle Language 14
Repeat 14
A-B Repeat 14
Clear 15
Zoom 15
Angle 15
Audio Channel 15

JPEG Disc Playback **15**
Repeat 15
Image Rotation 16
Zoom 16
Digest 16
USB Function 16

System Setup **17**
TV Display 17
Angle Mark 17
OSD (On Screen Display) Language 17
Captions 18
Screen Saver 18
Last Memory 18
Speaker Setup Page 18
SPDIF Output 19
LPCM Out 19
Dual Mono 19
DRC 19
Video Output 19
Resolution Setup Page 19
Video Quality Setup Page 20
HDMI Setup 20
Audio Source 20
Deep Colour 20
TV System 21
Audio 21
Subtitle 21
Disc Menu 21
Parental 22
Password Mode 22
Default 22

Maintenance **23**
Handling Discs 23
Cleaning Discs 23
Storing Discs 23

Hints and Tips **24**

Specifications **25**

Safety Warnings **26**

Congratulations on the purchase of your new Sandstrøm DVD Player.

We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Unpacking

Remove all packaging from DVD Player. Retain the packaging. If you dispose of it please do so according to local regulations.

The following items are included:

DVD Player



Remote Control
(P.N.: 1-3000-A599-0001-R)

Instruction Manual
(P.N.: 1-3090-A599-0002-R)



Quick Start Guide
(P.N.: 1-3010-A599-0002-R)

If items are missing or damaged, please contact Partmaster (UK only).
Tel: 0844 800 3456 for assistance.

Sandstrom S1HDVD10_IB_100617_Zell.indd 3 17/06/2010 10:29 AM

Product Overview

Front Panel



No	Control	Function
1	**STANDBY/ON** button	To turn the power on or restore the DVD player to standby mode.
2	Power Indicator	Illuminate red when the DVD player is in standby mode and light off when the DVD player is power on.
3	Disc Tray	To load a disc into the disc drive.
4	⏏ **OPEN/CLOSE** button	To open and close the disc tray.
5	LED Screen	Show information about the current status of the DVD player.
6	Remote Control Sensor	Receive infrared signals from the remote control.
7	USB Interface	Connection for a USB Flash Drive.
8	**PLAY/PAUSE** button	To start playback/stop playback momentarily.
9	**STOP** button	To stop playback.

Rear Panel



No	Control	Function
1	Power Line Input	Connect the supplied mains cable to the mains socket.
2	HDMI Output	Connect to a TV, a monitor or an AV amplifier equipped with a HDMI input terminal.
3	2 Channels Audio Output	Connect to a stereo system equipped with an AUDIO input terminal.
4	SCART Output	Connect to a TV or a monitor equipped with a composite video input terminal.

Sandstrom S1HDVD10_IB_100617_Zell.indd 4 17/06/2010 10:29 AM

Remote Control



No	Control	Function
1	**OPEN/CLOSE ⏏**	To open or close the DVD disc tray.
2	**DVD/USB**	To switch between DVD and USB as the input source.
3	**OSD** (On screen Display)	To display the disc information.
4	**SUBTITLE**	To switch between different subtitle languages. (Available languages depend on the DVD features)

Sandstrom S1HDVD10_IB_100617_Zell.indd 5 17/06/2010 10:29 AM

No	Control	Function
5	**TITLE**	To go back to the previous menu or show title menu.
6	**SEARCH**	To search and start playback from a selected point on the disc.
7	**REPEAT**	To select between different repeat modes – REPEAT CHAPTER, REPEAT TITLE, REPEAT ALL.
8	**A-B RPT**	To repeat playback between 2 particular points on a disc.
9	**SETUP**	To display the Setup Menu of the DVD.
10	**ENTER/PLAY ▶**	To confirm the selection or play the DVD disc.
11	**ZOOM**	To enlarge the picture on the TV.
12	**F.REV ◀◀**	To fast reverse during playback.
13	**F.FWD ▶▶**	To fast forward during playback.
14	**PAUSE/STEP** ⏸ / ⏯	To play or move the playback forward frame by frame.
15	**STOP ■**	To stop the playback.
16	**STANDBY ⏻**	To turn the power on or restores the DVD player to standby mode.
17	**0–10+**	To select the numeric items in a menu.
18	**ANGLE**	To switch / change the camera angle during playback. (If it is available in the DVD features)
19	**CLEAR**	To clear and cancel the previous input information.
20	**MENU**	To enter or exit the disc contents menu.
21	**CURSOR** ▲▼◀▶	To move up, down, left and right in the Setup Menu ◀ / ▶ Starts the forward and reverse search during playback. ▲ / ▼ Allows slow forward and backward during playback.
22	**PROG**	To program and view the selected starting point of a chapter and title in the DVD disc.
23	**NEXT ⏭**	To skip to the next title, chapter or track.
24	**PREV ⏮**	To return back to the previous title, chapter or track.
25	**MUTE**	To mute and restore your DVD sound output.
26	**AUDIO**	To change the audio mode.
27	**VOLUME +/–**	To increase and decrease the volume.

Sandstrom S1HDVD10_IB_100617_Zell.indd 6 17/06/2010 10:29 AM

Installing the Batteries

1. Press and lift the back cover up to open the battery compartment of the remote control.



2. Insert two AAA size batteries (not supplied).



> Install the batteries correctly by following the polarity (+ and -) indications in the battery compartment.

3. Close the battery compartment cover.



> Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Handling the Batteries

- Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause fire, personal injury or damage to property.
- When the batteries are exhausted, the remote will not function. Replace both batteries at the same time with new ones.
- Only use the battery type indicated in this manual.
- Do not install new batteries with used one and do not mix different types of batteries.
- Do not dispose of used batteries as domestic waste. Dispose of them in accordance with local regulations.

Sandstrom S1HDVD10_IB_100617_Zell.indd 7 17/06/2010 10:29 AM

Handling the Remote Control

- Take care of your fingernails when you press and hold the battery release tab.
- To avoid possible failure, read the following instructions and handle the remote control properly.
- Do not drop or cause impact to the remote control.
- Do not spill water or any liquid on the remote control.
- Do not place the remote control on a wet object.
- Do not place the remote control under direct sunlight or near sources of excessive heat.
- Remove the batteries from the remote control when not in use for a long period of time, as it could cause corrosion or battery leakage and may result in physical injury and/or property damage including fire.

Remote Control Operation Range

Point the remote control at the DVD player no more than 5 metres from the remote control sensor and within 60° of the front of the DVD player. The operating distance may vary depending on the brightness of the room.



Sandstrom S1HDVD10_IB_100617_Zell.indd 8 17/06/2010 10:29 AM

Connections



1. Connecting to a TV with an HDMI Cable

Use the HDMI cable (not supplied) to connect between the DVD player's HDMI OUT and the TV's HDMI IN.

2. Connecting to a TV with a SCART Cable

Use the SCART cable (not supplied) to connect between the DVD player's SCART OUT and the TV's SCART IN.

If your DVD player will not be connected to a stereo system or an AV receiver, a SCART or an HDMI connection is sufficient for both audio and video connections between your DVD player and TV.

3. Connecting to a Stereo System with an Audio Cable

Use the audio cables (not supplied) to connect AUDIO OUT (L/R) socket of the DVD player to AUDIO IN on the Stereo System. (Audio Left = White; and Audio Right = Red)

Sandstrom S1HDVD10_IB_100617_Zell.indd 9 17/06/2010 10:29 AM

Connecting to the Mains Socket

1. After all connections are properly completed, connect the mains cable into the mains socket. Never make or change any connections when the DVD player is connected to the mains socket.
2. Press the **STANDBY/ON** ⏻ button on the DVD player or the ⏻ button on the remote control to turn the DVD player on.
3. When the DVD player is power on and there is no disc in it, the display panel will show "NONE" to indicate there is no disc in the DVD Player.



Sandstrom S1HDVD10_IB_100617_Zell.indd 10 17/06/2010 10:29 AM

Compatible Disc Types

Disc Types	Disc Logo	Recorded Content
DVD-VIDEO (Digital Versatile Disc)		AUDIO + VIDEO
DVD±RW (Audio/Video format or JPEG files)		AUDIO + VIDEO + JPEG
DVD±R (DVD Recordable - Audio/Video format or JPEG files)		AUDIO + VIDEO + JPEG
CD-R (CD Recordable - Audio/Video format or JPEG files)		AUDIO + VIDEO + JPEG
CD-RW (CD-Rewritable - Audio/Video format or JPEG files)		AUDIO + VIDEO + JPEG
AUDIO-CD (Compact Disc Digital Audio)		AUDIO

Supported Formats

JPEG

- The file extensions has to be .jpg and not .jpeg
- Pictures encoding must comply with JPEG/ISO format.
- This DVD player can only display DCF-standard still pictures or JPEG pictures such as TIFF.

Some recorded files may not be able to be played due to the type and format of disc or condition of the recording.

Region Code

Both the DVD player and the discs are coded by region. These regional codes must match in order to play the disc. If the codes do not match, the disc will not play.

The Region Number for this DVD player is described on the rear panel of the DVD player.

Disc Type	DVD-VIDEO
Region code	2

Sandstrom S1HDVD10_IB_100617_Zell.indd 11 17/06/2010 10:29 AM

Start Up

Press the **STANDBY/ON** ⏻ button on the DVD player or remote control. Turn on the TV and select the video input connected to the DVD player.

Basic Playback

1. Press the **OPEN/CLOSE** ⏏ button to open the disc tray, place a disc into the disc tray with the label facing up.
   - For a double-sided disc, load the side which you want to play facing down.
   - There are two different disc sizes. Place the disc in the correct guide on the disc tray. If the disc is out of the guide, it may damage the disc and cause the DVD player to malfunction.
   - Do not place a disc which is unplayable in this DVD player.
2. Press the **OPEN/CLOSE** ⏏ button to close the disc tray, the playback will automatically start.
   - Some discs may not playback automatically, you can press the **ENTER/PLAY** ▶ button to start playback.
3. Depending on the disc, a menu may appear on the TV screen by pressing the **MENU** button. Press the ▲▼◀▶ buttons on the remote control to select menu options and press the **ENTER/PLAY** ▶ button to start, or press digits to select a menu options directly.

Stop Playback

1. Press the **STOP** ■ button to go to pre-stop mode, the TV screen will display "Press Play Key to Continue". With some discs, the DVD player can recall the stopped location, such as on DVDs and on audio CDs.
2. Press the **ENTER/PLAY** ▶ button to resume playback from the location where playback was stopped or from the beginning of the disc.
3. Press the **STOP** ■ button twice to stop completely.

Previous and Next

1. During playing, press the **PREV** ⏮ button to go back to the start of the previous chapter. Each press of this button will skip a chapter until the start of the disc.
2. Each press of the **NEXT** ⏭ button during playing will skip the current chapter and play the next one.

Fast Forward and Fast Reverse

1. Press the **F.FWD** ▶▶ button to fast forward through the disc. Each time the **F.FWD** ▶▶ button is pressed, the fast forward motion speed changes.
2. Press the **ENTER/PLAY** ▶ button to resume normal playback.
3. Press the **F.REV** ◀◀ button to fast reverse through the disc. Each time the **F.REV** ◀◀ button is pressed, the fast reverse motion speed changes.
4. Press the **ENTER/PLAY** ▶ button to resume normal playback.

Sandstrom S1HDVD10_IB_100617_Zell.indd 12 17/06/2010 10:29 AM

Pause Playback

1. Press the **PAUSE/STEP** ⏸ / ⏸► button to pause playback (still mode). The sound will be muted during still mode.
2. Press the **ENTER/PLAY** ► button to resume normal playback.

Single Step Playback

1. Press the **PAUSE/STEP** ⏸ / ⏸► button repeatedly during PAUSE mode to play in step.
2. Press the **ENTER/PLAY** ► button to resume normal playback.

Volume Adjustment

1. Press the **VOL +/-** button to adjust the volume.
2. Press the **MUTE** button to switch the sound off. Press the **MUTE** button again or the **VOL +/-** button to cancel this function.

"⊘" may appear on the TV screen during operation. "⊘" means that the operation is not permitted by the DVD Player or the disc.
The DVD Player will switch to screen saver mode after being idle for sometime. Press any button to exit the screen saver.

Advanced Playback

The following functions are applicable only to DVD discs. If other disc formats are played, the screen display and operation will be different.

DVD/USB

1. Press **DVD/USB** button to display the screen menu.
2. Press the ▲▼ buttons on the remote control to navigate in the menu, and then press the **ENTER/PLAY** ► button to make your selection.

Please do not pull out the USB when reading in order to avoid damage to your USB device.
If no USB device is connected, detecting USB will show "Not Find Device".

Search

1. Press the **SEARCH** button once, and the screen will display the search menu.
2. Press the ▲▼ buttons to select the item that you want, then press the **ENTER/PLAY** ► button to confirm.

Sandstrom S1HDVD10_IB_100617_Zell.indd 13 17/06/2010 10:29 AM

Program

1. Press the **PROG** button and the screen will display the info window.
2. Press the **0-10+** buttons to input the desired chapter and title (for DVD movie) or track number (for Audio CD).
3. Press the ▲▼◀▶ buttons to select the **START** logo and press the **ENTER/PLAY ▶** button to play. At this time the DVD player will start program playback and the screen will display the **"PROGRAM"** logo.
4. Press the **STOP ■** button twice or press the **PROG** button again and select the **STOP ■** button if you want to cancel this function.

OSD

Press the **OSD** button and the screen will display some information about the disc, such as: "Title Elapsed", "Title Remain", "Chapter Elapsed", "Chapter Remain" and "Display Off".

Title

With some DVD discs, press the **TITLE** button to display the title menu. You can press digits to select the chapters preferred. Press the **ENTER/PLAY ▶** button to play. (Depending on the DVDs)

Subtitle Language

1. Press the **SUBTITLE** button repeatedly to switch between different subtitle languages that are available in the disc.
2. The screen will display "SUBTITLE 01/XX XXXXX", where "01" indicates the original number of this language; "XX" indicates the total number of languages; "XXXXXX" indicates the name of the selected language. (The number of languages depends on the disc).

Repeat

Press the **REPEAT** button repeatedly to select different repeat modes.

Press Once	↻ Chapter (Repeat Chapter)
Press Twice	↻ Title (Repeat Title)
Press Three Times	↻ All (Repeat All)
Press Four Times	All repeat functions are cancelled

A-B Repeat

Repeat a section between points A and B within a Title / Chapter / Track.

1. Press the **A-B RPT** button to choose a starting point A.
2. Press the **A-B RPT** button again to set an ending point B and complete the setting.
3. The selected section A-B will be repeated. Press the **A-B RPT** button the third time to cancel and exit.

Sandstrom S1HDVD10_IB_100617_Zell.indd 14 17/06/2010 10:29 AM

Clear

Press the **CLEAR** button during information input to cancel the previous input.

Zoom

1. Press the **ZOOM** button to enlarge pictures. Each time the **ZOOM** button is pressed, the picture enlarges in sequence.
2. Press the ▲▼◀▶ buttons to navigate in the enlarged picture.

Angle

Press the **ANGLE** button repeatedly to switch between different camera angles that are available in the disc.

Audio Channel

Press the **AUDIO** button on the remote control repeatedly to change the audio mode.

For example: Audio 1/2: Dolby D 2 CH English
Audio 2/2: Dolby D 5.1 CH English

The number of audio tracks available depends on the disc.

JPEG Disc Playback

When a JPEG disc is inserted into the DVD player, a navigation menu will be displayed automatically.

- In the menu, use the ▲▼ buttons to select a file, then press the **ENTER/PLAY** ▶ button to start the slide show. Press the **PREV** ⏮ button or the **NEXT** ⏭ button during the slide show, to return to the previous or to skip to the next picture. Press the **PAUSE/STEP** ⏸ / ⏯ button during the slide show to pause the current picture. Then, press the **ENTER/PLAY** ▶ button to resume the slide show.

Some JPEG discs may not be played due to the configuration and characteristics of the discs or condition of the recording.

- Press the **PROG** button repeatedly to change the slide show effect.

Repeat

- Press the **REPEAT** button repeatedly to play the single photo. You can choose to repeat the photo playback by once or by folder. Press the **REPEAT** button again to cancel the repeat mode.

Sandstrom S1HDVD10_IB_100617_Zell.indd 15 17/06/2010 10:29 AM

Image Rotation

- There are four modes to rotate a picture: "Invert", "Mirror", Left", and "Right". These operations are allowed only when a picture is being displayed normally and will be cancelled automatically when a new picture is displayed. The arrow keys are used to select the different rotation modes:

▲ - Invert / Normal
▼ - Mirror / Normal
◀ - Turn left
▶ - Turn right

Zoom

- The **ZOOM** button is used to turn on or off this function. When this mode is on, the pictures will be displayed at the last ratio selected by the user. A message on the screen will indicate the current zoom ratio.
- If ZOOM mode is on, the **F.REV** ◀◀ / **F.FWD** ▶▶ buttons are used to control the ratio of zoom in/out. With ZOOM mode off, a picture is scaled to fit the whole TV screen.

During zoom function, slide-show transition and image rotation are disabled. To cancel the zoom function press the **ZOOM** button again to resume the slide-show.

Digest

- The **STOP** button is used to display thumbnail size pictures. After it is enabled, some scaled-down thumbnail pictures will be displayed on the screen. The **PREV** ⏮ / **NEXT** ⏭ buttons can be used to display the next / previous pictures in the JPEG disc.
- You can select any of the displayed thumbnails by using the ▲ ▼ ▶ ◀ buttons and pressing the **ENTER/PLAY** ▶ button.
- The thumbnail will enlarge to fit the TV screen and the slide show will start. If you desire to display an image indefinitely, press the **PAUSE/STEP** ⏸ / ⏯ button. To view the next or previous picture press the **PREV** ⏮ / **NEXT** ⏭ buttons. To resume the slide show press the **ENTER/PLAY** ▶ button.

Quality of pictures displayed on the screen is highly dependent on the viewing device.

USB Function

The USB port allows you to playback your photos from your USB device. Please refer to the section "Advanced Playback → DVD/USB".

- The DVD player supports USB 1.1 devices and some USB 2.0 devices. Not all USB devices can be support . If your USB device is not compatible try another one.
- This DVD player can support USB flash memory devices with up to 2GB of storage. The compatibility with USB devices that are over 2GB is not guaranteed. USB hubs are not supported by this DVD player.
- MP3 players, digital cameras, mobile phones or camcorders may not be supported by this DVD player.

Sandstrom S1HDVD10_IB_100617_Zell.indd 16 17/06/2010 10:29 AM

System Setup

When you press the **SETUP** button on the remote control, the setup menu will be displayed.

1. Within the setup menu, you can use the ▲▼►◄ buttons on the remote control to move the cursor, and then press the **ENTER/PLAY** ► button to make your selection. Press the ◄ button to return to the previous menu.
2. To exit the setup menu, press the **SETUP** button again.

1. General Setup Page

Setup TV screen format, video type and all DVD functions.



TV Display

In order to display the playback in the correct size format, both the DVD player and the TV should select the same display size format.

- **Normal / PS**

  Select this if you have a standard TV and want both sides of the picture to be trimmed or formatted to fit your TV screen.
- **Normal / LB**

  Select this if you have a standard TV and want to display upper and lower bands with a wide-screen picture display.
- **Wide**

  Select this if you have a wide-screen TV.

- No matter which display format is selected, a picture recorded in standard 4:3 format always displays in the 4:3 aspect ratio.
- The display format of DVD titles may vary; please refer to the information that accompanies your specific DVD title.
- If the DVD title is recorded in 16:9 wide display format while the TV is a standard 4:3 screen, horizontal compression of the image will result.
- Some DVD titles may be recorded in special formats. In such cases, the DVD titles will always appear on the screen in their original format, regardless of which TV display format you select.

Angle Mark

You can select a particular camera angle when playing a DVD that offers multiple angles.

OSD (On Screen Display) Language

Allows you to select the setup menu and OSD language.

Sandstrom S1HDVD10_IB_100617_Zell.indd 17 17/06/2010 10:29 AM

Captions

For hearing-impaired people, the program can be displayed with recorded explanatory captions.

This is valid for a disc that has captions.

Screen Saver

1. Select **ON** to display the screen saver. A moving DVD logo appears on a dark screen when disc playback is stopped, paused, or you have not used the player or the remote control for more than 5 minutes when the power is still on.
2. Select **OFF** to turn off the screen saver function.

Last Memory

1. Select **ON** to activate the Last Memory function. This function is convenient when you want to continue viewing a disc from the point where you were last watching it. Unlike the resume function, the Last Memory function is effective even if the DVD has been removed from the player.
2. Select **OFF** to turn off the Last Memory function.

2. Audio Setup Page

Speaker Setup Page

Downmix Setup

Set front speakers to Lt/Rt or Stereo.

- **Lt / Rt**

  Select this option if your DVD player is connected to a Dolby decoder.

- **Stereo**

  Select this option to change channel output to stereo which delivers sound from only the two front speakers.





Sandstrom S1HDVD10_IB_100617_Zell.indd 18 17/06/2010 10:29 AM

SPDIF Setup Page



SPDIF Output

Select the SPDIF Output.

- **SPDIF Off**

  Turns off the SPDIF output.
- **SPDIF/RAW**

  If you have connected your DIGITAL AUDIO OUT to a multi-channel decoder/receiver.
- **SPDIF/PCM**

  Only if your receiver is not capable of decoding multi-channel audio.

LPCM Out

Select sound quality from 48K/96K.

3. Dolby Digital Setup Page

Dual Mono



If your amplifier / decoder has Dolby Digital output, you may select stereo, left mono, right mono, or mixed mono mode for your amplifier decoder.

DRC

This function is generally used when playing high volume programs at night to minimise disturbances. This setting can dynamically lower the volume and still keep
the original tone quality. This is the range, measured in decibels (dB), between the loudest and the quietest sound registers in a sound track.

4. Video Setup Page

SCART Output



RGB and CVBS video signal can be set.

Resolution Setup Page

You can select the resolution output of the player from HDMI to match your TV. (The Video Output option must select "HDMI", the Resolution option is valid.)

Sandstrom S1HDVD10_IB_100617_Zell.indd 19 17/06/2010 10:29 AM

Video Quality Setup Page



- ***Sharpness***
  Set the sharpness level of video output.
- ***Brightness***
  Set the brightness level of video output.
- ***Contrast***
  Set the contrast level of video output.
- ***Gamma***
  Sets the gamma level of the video.
- ***Hue***
  Set the hue level of the video.
- ***Saturation***
  Set the saturation level of the video.
- ***Luma Delay***
  Set the luminance delay of video output depend on the TV's brightness and colour. It sets as 1T commonly for DVD.

5. HDMI Setup Page

HDMI Setup

You can turn HDMI output On or Off.



Audio Source

You can set the audio source as Auto or PCM (Pulse Code Modulation).

Deep Colour

Enrich the picture colour.

Sandstrom S1HDVD10_IB_100617_Zell.indd 20 17/06/2010 10:29 AM

6. Preference Setup Page

The preference setting is only active when there is no DVD disc in the player or the DVD player is in **STOP** mode. The setting will be saved and effective whenever the player is power on.

TV System



In order for the disc to play, the colour system of the DVD player, disc and TV should match.

- ***PAL***
  This is the format used in UK.
- ***NTSC***
  This format is used by some other countries. e.g. USA.

Audio

Allows you to choose the preferred audio language of your disc. If the preferred language is not available on the disc, the DVD player will automatically use the DVD disc's default language.

Subtitle

Allows you to choose the preferred subtitle language of your disc. If the preferred language is not available on the disc, the DVD player will automatically use the DVD disc's default language.

Disc Menu

Allows you to choose the preferred menu language of your disc. If the preferred language is not available on the disc, the DVD player will automatically use the DVD disc's default language.

Sandstrom S1HDVD10_IB_100617_Zell.indd 21 17/06/2010 10:29 AM

Parental

This feature allows you to block disc playback with specific ratings. The rating levels are from 1 to 8 and are country dependent. You can prohibit the playing of certain discs that are not suitable for your children, or you can have certain discs played with alternative scenes.

- Unlock the disc by entering the 6-digit password you have set in PASSWORD setup before you can access the RATING menu.

If you change the control level, you must input password. (Initial password : 136900)

- To disable the parental control and allow to play all discs, select **ADULT**.
- Use the **0-9** buttons to enter the 6-digit password again.
- The DVD discs that are rated above the selected level will not be played unless the 6-digit password is entered.

Tips:

The following disc types will not be affected by the Parental Control feature:

- Discs that are not coded by the disc manufacturer.
- Discs that are not coded by the disc manufacturer despite having a movie rating printed on the disc cover.
- CDs as they have no rating level indication.
- Most copied DVD discs or illegal DVDs.

Password Mode

The Parental Control can be set up in the DVD player to block video and to change password.

A 6-digit password will be required to play a prohibited disc.

If the disc is locked and the system prompts you to enter the password.

- Use the **0-9** buttons to enter your password.

In case you forgot your password, the master password is "**136900**".

To change your password, you will need to unlock the system by entering your password or the master password **"136900"**.

- Once the lock icon is unlocked, you need to enter your new 6-digit password.

Default

Resets to all the manufacturer's original settings for this DVD player. Press the **ENTER/PLAY** ▶ button to perform the reset.

Sandstrom S1HDVD10_IB_100617_Zell.indd 22 17/06/2010 10:29 AM

Maintenance

Handling Discs

- Do not touch the playback side of the disc.
- Do not attach paper or tape to the disc.



Cleaning Discs

- Fingerprints and dust on the disc cause picture and sound deterioration. Wipe the disc from the centre outwards with a soft cloth. Always keep the disc clean.



- If you cannot wipe off the dust with a soft cloth, wipe the disc lightly with a slightly moistened soft cloth and finish with a dry cloth.
- Do not use any type of solvent such as thinner, benzine, commercially available cleaners or antistatic spray. They may damage the disc.

Storing Discs

- Do not store discs in places subjected to direct sunlight or near heat sources.
- Do not store discs in places subjected to moisture and dust such as a bathroom or near a humidifier.
- Storing discs vertically in a case, stacking discs or placing objects on discs outside of their cases may cause warping.

Sandstrom S1HDVD10_IB_100617_Zell.indd 23 17/06/2010 10:29 AM

Hints and Tips

PROBLEM	SOLUTION
No operation can be performed with the remote control.	• Check the batteries in the remote control. They may need replacing. • Operate the remote control at a distance of no more than 6m. • Removes batteries and hold down one or more buttons for several minutes to drain the microprocessor inside the remote control to reset it. Reinstall batteries and try to operate the remote control again.
Disc does not play.	• Ensure that the disc is installed with the label side facing up. • Check the region number of the DVD.
Disc Menu does not appear.	• Check if the disc has a Menu.
No power	• Press the **STANDBY/ON** ⏻ button on the DVD or on the Remote Control to turn on the unit. • Make sure the mains socket has power.
The picture is distorted or turns black and white during colour playback.	• The disc does not match with the TV colour system standard (PAL/NTSC). • The disc is dirty. Clean the disc. • Sometimes a small amount of picture distortion may appear. This is not a malfunction of the unit.
The screen aspect ratio cannot be changed.	• The Screen Aspect Ratio is fixed on your DVDs. • Depending on the TV, it may not be possible to change the Screen Aspect Ratio. • This is not a problem with the DVD player.
No audio.	• Make sure you have securely connected the DVD player and other devices. • Make sure the TV and the amplifier are in good condition and are setup properly.
Not able to select some items in the setup/ system menu.	• Press the **STOP** ■ button twice before selecting the setup/system menu. • Depending on the disc availability, some menu items cannot be selected.

Sandstrom S1HDVD10_IB_100617_Zell.indd 24 17/06/2010 10:29 AM

PROBLEM	SOLUTION
The DVD player does not start the playback.	• Insert a readable disc with the playback side facing down. • Check the disc type, colour system (PAL/NTSC) and region code. • Check for any scratches or smudges on the disc. • Press SETUP button to turn off the setup menu . • Enter the password in order to change the parental rating level or to unlock the disc for playback. • Moisture may have condensed inside the system. Remove the disc and leave the system turned on for about an hour. • Disconnect the mains cable from the mains socket for a few minutes. Reconnect the mains cable and try to operate the DVD player.
Picture freezes momentarily during playback.	• Check the disc for fingerprint or scratches, and clean with a soft cloth wiping from centre to edge.

Specifications

VF Signal System	PAL/NTSC
Frequence Response	CD: 20Hz-20KHz(EIAJ) DVD: 20Hz-22KHz(48KHz)(Sample result) 20Hz-44KHz(96KHz)(Sample result)
Audio S/N Ratio	> 90 dB
Video/Picture	MPEG2
Audio	MPEG1 standard
Audio Output (Analog Audio)	Electric level output: 1.8V ± 0.2 resistance: 10K ohms
Video Output	Electric level output: 1.0Vp--p resistance: 75 ohms Unbalanced negative
Power	110V - 240V ~ 50/60Hz
Power Consumption	12W
Dimensions	L: 360mm W: 215mm H: 41mm
Weight	1.5 kg
Operating Temperature	5ºC to 35ºC (41ºF to 95ºF)
Operating Humidity	5% to 90%

Features and Specification are subject to change without notice.

Sandstrom S1HDVD10_IB_100617_Zell.indd 25 17/06/2010 10:29 AM

Safety Warnings

- Read all the instructions carefully before using the unit and keep them for future reference.
- Retain the manual. If you pass the unit onto a third party make sure to include this manual.
- Check that the voltage marked on the rating label matches your mains voltage.

Damage

- Please inspect the unit for damage after unpacking.
- Do not continue to operate the unit if you are in any doubt about it working normally, or if it is damaged in any way - switch off, withdraw the mains plug and consult your dealer.

Location of Unit

- The unit must be placed on a flat stable surface and should not be subjected to vibrations.
- Do not place the unit on sloped or unstable surfaces as the unit may fall off or tip over.
- The mains socket must be located near the unit and should be easily accessible.
- This unit is designed for indoor use only.

Temperature

- Avoid extreme degrees of temperature, either hot or cold. Place the unit well away from heat sources such as radiators or gas/ electric fires.
- Avoid exposure to direct sunlight and other sources of heat.

Naked Flames

- Never place any type of candle or naked flame on the top of or near the unit.

Moisture

- To reduce the risk of fire, electric shock or product damage, do not expose this unit to rain, moisture, dripping or splashing. No objects filled with liquids, such as vases, should be placed on the unit.
- If you spill any liquid into the unit, it can cause serious damage. Switch it off at the mains immediately. Withdraw the mains plug and consult your dealer.

Ventilation

- To prevent the risk of electric shock or fire hazard due to overheating, ensure that curtains and other materials do not obstruct the ventilation vents.
- Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure the unit is well ventilated.

Safety

- Always disconnect the unit from the mains supply before connecting/disconnecting other devices or moving the unit.
- Unplug the unit from the mains socket during a lightning storm.

Mains Cable

- Make sure the unit or unit stand is not resting on top of the mains cable, as the weight of the unit may damage the mains cable and create a safety hazard.
- If the mains cable is damaged it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

Standby

- The ⏻ button on the remote control does not switch off the unit completely. The unit will continue to draw electricity from the mains supply while in standby. In the interests of safety and to avoid unnecessary energy consumption, never leave the unit in standby while unattended for long periods of time, e.g. overnight, while on holiday or while out of the house. Switch it off and disconnect the mains plug from the mains socket.

Interference

- Do not place the unit on or near appliances which may cause electromagnetic interference. If you do, it may adversely affect the operating performance of the unit, and cause a distorted picture or sound.

Sandstrom S1HDVD10_IB_100617_Zell.indd 26 17/06/2010 10:29 AM

Batteries

- Batteries used in the remote control for this unit are easily swallowed by young children and this is dangerous.
- Keep loose batteries away from young children and make sure that the battery holder tray is secure in the remote control. Seek medical advice if you believe a cell has been swallowed.
- Please dispose of batteries correctly by following the guidance in this manual.

Supervision

- Children should be supervised to ensure that they do not play with the unit and the remote control.
- Never let anyone especially children push anything into the holes, slots or any other openings in the case - this could result in a fatal electric shock.

DVD

- **Class 1 Laser Product**
- This unit utilises a laser. Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

- Before moving the unit, ensure the disc tray is empty.
- Always remove the disc when the unit is not in use.
- Failure to do so will risk severely damaging the disc and the unit.
- Do not stack devices, heat from other devices may affect the performance of the unit.

The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the manual accompanying the unit.

Service

- To reduce the risk of electric shock, do not remove screws. The unit does not contain any user-serviceable parts. Please leave all maintenance work to qualified personnel.
- Do not open any fixed covers as this may expose dangerous voltages.

Maintenance

- Ensure to unplug the unit from the mains socket before cleaning.
- Do not use any type of abrasive pad or abrasive cleaning solutions as these may damage the unit's surface.
- Do not use liquids to clean the unit.

Sandstrom S1HDVD10_IB_100617_Zell.indd 27 17/06/2010 10:29 AM

NOTE: If you require a replacement for any of the items listed below, please quote their corresponding part numbers:	
Replacement Part	**Part Number**
Remote Control	1-3000-A599-0001-R
Instruction Manual	1-3090-A599-0002-R
Quick Start Guide	1-3010-A599-0002-R

Partmaster.co.uk

Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call 0844 800 3456 (UK customers only) Calls charged at National Rate.

Notes for battery disposal

The batteries used with this product contain chemicals that are harmful to the environment. To preserve our environment, dispose of used batteries according to your local laws or regulations. Do not dispose of batteries with normal household waste.

For more information, please contact the local authority or your retailer where you purchased the product.

This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.

HDMI, the HDMI Logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

All trademarks are the property of their respective owners and all rights are acknowledged.

DSG Retail Ltd • Maylands Avenue • Hemel Hempstead
Herts • HP2 7TG • England

(P.N. 1-3090-A599-0002-R)

Sandstrom S1HDVD10_IB_100617_Zell.indd 29 17/06/2010 10:29 AM